

CV Practice Class

4. Camera Calibration and 3D Reconstruction

2017-07-06

FIRA 인공지능 에이전트 과정
SNUVL Lab

Contents

1. About 3D Reconstruction
2. Camera Calibration
3. ~~Pose Estimation (skip)~~
4. ~~Epipolar Geometry (skip)~~
5. Binocular Stereo

About 3D Reconstruction

1. If you want to know A-to-Z about Multi-View Geometry, there is AWESOME tutorial, [SFMedu](#), from Princeton university.
2. If you want to build Multi-View Geometry application, OpenCV is NOT a good choice.
Try [OpenMVG](#) and [OpenMVS](#) and [PCL](#)
3. If you want to know useful materials about 3D vision, visit [awesome_3DReconstruction_list](#)

Goal of Multi-view Stereo System

Get 3D structure from multiple 2D images!



Camera Calibration

Camera Model

Lens Distortion




Camera Calibration

Camera Model

$$\begin{array}{ccccc}
 \begin{bmatrix} u \\ v \\ 1 \end{bmatrix} & = & \begin{bmatrix} fk_u & 0 & u_0 \\ 0 & fk_v & v_0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \end{bmatrix} \begin{bmatrix} R & T \\ 0^T & 1 \end{bmatrix} \begin{bmatrix} X_w \\ Y_w \\ Z_w \\ 1 \end{bmatrix} \\
 \text{Image coord.} & & \text{Camera internal parameter} & \text{Perspective projection} & \begin{array}{l} \text{3-D point in camera coord.} \\ \text{3-D point in world coord.} \end{array}
 \end{array}$$

$$\mathbf{x} = \underbrace{\mathbf{A}}_{\text{Intrinsic}} [\underbrace{\mathbf{R} \mid \mathbf{t}}_{\text{Extrinsic}}] \mathbf{X}$$

World \longrightarrow Camera \longrightarrow Image



Camera Model

[Camera model demo](#)

f_x, f_y : focal lengths expressed in pixel units


c_x, c_y : principal point that is usually at the image center

s : skew coefficient. Usually 0

$$K = \begin{pmatrix} f_x & s & x_0 \\ 0 & f_y & y_0 \\ 0 & 0 & 1 \end{pmatrix}$$
$$= \underbrace{\begin{pmatrix} 1 & 0 & x_0 \\ 0 & 1 & y_0 \\ 0 & 0 & 1 \end{pmatrix}}_{\text{2D Translation}} \times \underbrace{\begin{pmatrix} f_x & 0 & 0 \\ 0 & f_y & 0 \\ 0 & 0 & 1 \end{pmatrix}}_{\text{2D Scaling}} \times \underbrace{\begin{pmatrix} 1 & s/f_x & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{pmatrix}}_{\text{2D Shear}}$$

Camera Model

When people take SAME object with SAME camera...




Camera Calibration


	Point 1	Point 2	Point 3
Image 1	$\mathbf{x}_1^1 = \mathbf{K}[\mathbf{R}_1 \mathbf{t}_1] \mathbf{X}^1$	$\mathbf{x}_1^2 = \mathbf{K}[\mathbf{R}_1 \mathbf{t}_1] \mathbf{X}^2$	
Image 2	$\mathbf{x}_2^1 = \mathbf{K}[\mathbf{R}_2 \mathbf{t}_2] \mathbf{X}^1$	$\mathbf{x}_2^2 = \mathbf{K}[\mathbf{R}_2 \mathbf{t}_2] \mathbf{X}^2$	$\mathbf{x}_2^3 = \mathbf{K}[\mathbf{R}_2 \mathbf{t}_2] \mathbf{X}^3$
Image 3	$\mathbf{x}_3^1 = \mathbf{K}[\mathbf{R}_3 \mathbf{t}_3] \mathbf{X}^1$		$\mathbf{x}_3^3 = \mathbf{K}[\mathbf{R}_3 \mathbf{t}_3] \mathbf{X}^3$

Same Camera Same Setting = Same **K**

Lens Distortion



negative radial distortion
"pincushion"



no distortion



positive radial distortion
"barrel"

Lens Distortion

- We will use Brown's distortion model with 5-parameters

$$[k_1, k_2, p_1, p_2, p_3]$$

- The distortion is solved as follows:

$$x_{corrected} = x(1 + k_1r^2 + k_2r^4 + k_3r^6)$$

$$y_{corrected} = y(1 + k_1r^2 + k_2r^4 + k_3r^6)$$


Camera Calibration

- We will use chessboard for camera calibration




Camera Calibration

- First, take multiple chessboard images



Camera Calibration


- Second, run calibration algorithms




(Image credit: Caltech Vision lab)

Camera Calibration

- Calibration results



Before calibration




After calibration

Camera Calibration: Find Chessboard Patterns

- Find chessboard corners from gray-scale image

```
found, corners = cv2.findChessboardCorners(img, pattern_size)
```

- `img`: chessboard image. 8-bit grayscale or color image.
- `pattern_size`: Number of inner corners per a chessboard row and column. e.g. (7, 6)
- `found`: True if chessboard found else False.
- `corners`: output array of detected corners





Camera Calibration: Find Chessboard Patterns

- Refines corner locations (**Note that there is no return value!**)

```
cv2.cornerSubPix(gray, corners, winsize, zerozone, criteria)
```

- `gray`: input image
- `corners`: initial coordinates of the input corners and refined coordinates provided for output
- `winsize`: half of the side length of the search window
- `zerozone`: output array of detected corners. (-1, -1) if there is no such region
- `criteria`: criteria for termination of the iterative process of corner refinement



Camera Calibration: Calibrate!

- Chessboard operator in OpenCV

```
ret, mtx, dist, rvecs, tvecs = cv2.calibrateCamera(objpoints,  
imgpoints, imgsize, None, None)
```

- `objpoints`: (X, Y, Z) coordinates of chessboard patterns
- `imgpoints`: (X, Y) coordinate of chessboard pattern in image
- `imgsize`: image size in (width, height)
- `ret`: RMS error of camera calibration
- `mtx`: camera intrinsic parameter matrix
- `dist`: distortion coefficients
- `rvecs`: output vector of rotation vectors
- `tvecs`: output vector of translation vectors

Camera Calibration: Refine Camera Matrix

- Refine camera intrinsic matrix

```
newcameramatrix, roi = cv2.getOptimalNewCameraMatrix(mtx, dist,  
imgsize, alpha, new_imgsize)
```

- `mtx`: input camera matrix
- `dist`: input factor of distortion coefficients
- `imgsize`: original image size
- `alpha`: free scaling parameter between 0 and 1
- `new_imgsize`: image size after rectification
- `newcameramatrix`: output new camera matrix
- `roi`: output rectangle that outlines all-good-pixels region in the undistorted image

Camera Calibration: Undistort Image

- Refine camera intrinsic matrix

```
dst = cv2.undistort(img, mtx, dist, None, newcameramt)
```

- `img`: input (distorted) image
- `mtx`: input camera matrix
- `dist`: input vector of distortion coefficients
- `newcameramt`: refined camera matrix
- `dst`: output (corrected) image that has the same size as `img`

Camera Calibration: Calculate RMS Error

- Projection operator in OpenCV

```
imagePoints, _ = cv2.projectPoints(objPoints, rvec, tvec,  
cameraMatrix, dist)
```

- `objpoints`: (X, Y, Z) coordinates of chessboard patterns
- `rvec`: rotation vector
- `tvec`: translation vector
- `cameraMatrix`: camera intrinsic matrix
- `dist`: distortion coefficients
- `imagePoints`: projected points

Camera Calibration: Calculate RMS Error

- Norm operator in OpenCV

```
error = cv2.norm(src, tgt, normType)
```


- src: input array
- dst: target array
- normType: normalization type
 - cv2.NORM_INF
 - cv2.NORM_L1
 - cv2.NORM_L2

Let's Check the Code

1_camera_calibration.ipynb

Binocular Stereo


Disparity and Depth
Window search



Stereo Camera




Disparity and Depth



Disparity and Depth

Assume parallel optical axes, known camera parameters. **What is expression for Z?**



$$\frac{B + x_l - x_r}{Z - f} = \frac{B}{Z}$$

$$Z = f \frac{B}{\underbrace{x_r - x_l}_{\text{disparity}}}$$

Depth from Disparity

image $I(x,y)$



Disparity map $D(x,y)$





image $I'(x',y')$



$$(x',y')=(x+D(x,y), y)$$


So if we could find the **corresponding points** in two images, we could **estimate relative depth**...

Correspondence Search with Similarity




Slide a window along the right scanline and compare contents of that window with the reference window in the left image

Effect of Window size



$W = 3$



$W = 20$

Smaller window

- + More detail
- More noise

Larger window


- + Smoother disparity maps
- Less detail

Create Disparity Map

- Binocular stereo operator in OpenCV

```
stereo = cv2.StereoBM_create(numDisparity, blockSize)
disparity = stereo.compute(imgL, imgR)
```

- numDisparity: disparity search range
- blockSize: size of blocks for window search
- stereo: StereoBM object
- imgL: left image
- imgR: right image
- disparity: output disparity of input images



Let's Check the Code

2_binocular_stereo.ipynb

Reference

- OpenCV-Python Tutorials

http://docs.opencv.org/3.0-beta/doc/py_tutorials/py_tutorials.html